Science & Motion Sports

SAM PuttLab

Installation Guide

Thank you for choosing the SAM PuttLab system!

This Installation describes the hardware and software installation process and the "Measurement"-feature in a simple way.

For optimal results first read the section "General information" on page 2.

Based on the "Delivery checklist" on page 4 please check that all items listed are included in the package.

Follow the sequence of the steps to avoid problems during installation.

Installation steps:

- Hardware installation page 5
- Software installation page 9
- Start software for the first time page 12
- Do your first measurement page 14



1. General information

SAM PuttLab is an analysis and training system based on ultrasound technology. It analyzes more than 40 important parameters of your putting stroke and displays the results in easy to understand graphic reports.

Minimum hardware requirements: Pentium IV with at least 1.5 GHz, 2 GB RAM, 250 MB free on your hard drive, free USB port. Software requirements: Windows Vista, 7, 8, 10 (32 or 64 Bit). Science & Motion Sports takes no responsibility if the system does not work properly under lower hardware and software specifications.

- This Installation Guide gives you a quick overview for the installation of the SAM PuttLab. After installation please read the complete operating manual on the included PuttLab setup stick for further details, or press F1 in the SAM PuttLab software to open the corresponding page in the manual.
- If you want to use the SAM PuttLab indoors, choose a place with a minimum distance of 1 meter / 3 feet to walls or other objects placed on the ground. Generally it could be a problem to do measurements in very small rooms with wall distances of less than 2-3 m (6.5-10 ft).
- After positioning the PuttLab base unit please be sure that no other objects like chairs, boxes etc. are placed inside a range of 1.5 meters / 5 feet from the unit. Objects close to the Base Unit could lead to interferences of the ultrasonic signals and may reduce the quality of recordings.
- If you use the SAM PuttLab outdoors, protect the system against direct rain. Both the Triplet and the BaseUnit are not water resistant! If there is a strong or stormy wind during the recordings this will have impact to the signal quality (noise). Try to find a place where the system is protected from the wind (maybe use a windshield).
- Please note that the automatic stroke recognition, the result data display and rating of the strokes is optimized for a putt length of 3-5 m (10-16 ft) on a stimp of 10.
- To operate the FlexTriplet you need a Lithium battery of type CR2 (photo battery). The batteries included in this package are not rechargeable. Do not try to recharge them!
- If you have any problem with the SAM PuttLab please contact us via email: <u>support@scienceandmotion.com</u> or use the support form online on <u>www.scienceandmotion.de</u>.

Safety warnings

2. Safety warnings



2.1 General handling precautions

- I Do not take apart/modify the equipment in any manner other than described in the manual. *Fire or electrical shock may result from improper handling of its components.*
- I If you hear unusual noises, see smoke, feel excessive heat or smell anything unusual, immediately unplug the USB cable and contact your retailer. *Continued use may result in fires or electrical shock.*
- I When cleaning the equipment, use a well-wrung, water-moistened cloth. Do not use flammable liquids, such as alcohol, benzene or thinners. *If a flammable liquid enters the inner electrical parts, fire or electrical shock may result.*
- I Some of the package components are shipped inside plastic bags.
 These bags can be dangerous.
 To avoid danger of suffocation, keep the plastic bags away from babies and children!

2.2 Transport and storage

- You can easily take the SAM PuttLab wherever you want within the original case. Please insert the parts into the case as they were shipped. Don't store it in a damp or wet place!
- When not in use for extended periods of time, remove the battery from the Triplet. Also unplug the USB cable for safety.

2.3 About locations for usage of SAM PuttLab

- I Do not place the equipment near flammable liquids such as alcohol or thinners. If these come in contact with internal electrical parts fire or electrical shock may result.
- I Do not place the following objects on top of the equipment:
 - 1. Metallic objects, such as necklaces.
 - 2. Containers with liquid, such as cups, vases, and flower pots.

If the internal electrical parts come in contact with these, fire or electrical shock may result. If any of these objects or liquids enter the equipment, immediately unplug the USB cable and contact you retailer.

- I Do not place the equipment in the following areas:
 - 1. Areas with high temperatures (higher than 60°).
 - 2. Areas near flame sources.

Fire or electrical shock may result.

Delivery checklist

3. Delivery checklist



Hardware installation

4. Hardware installation

Needed parts:

		į	Science & Motion Sports Treat Auge Catination	Manual Angle Ang
Base Unit	FlexTriplet with FlexClip	Tripod	Triplet Calibration Sheet	Battery

4.1 Inserting the battery



4.2 Mount the FlexTriplet to a putter



Hardware installation



- 8. Place the putter head on the Triplet Calibration Sheet.
 - The FlexTriplet has to be mounted to the putter head with an angle of 90°. The Triplet Calibration Sheet will help you.
- Adjust the angle between putter head and FlexTriplet (exactly to 90°) by using the line on the sheet.
- 10. Fasten the FlexClip screws.
 - If you lost the Triplet Calibration Sheet, you can find a copy on the PuttLab Setup Stick.

4.3 Setting up the BaseUnit with Tripod



ø

Hardware installation

No Slope!	5.	Place the BaseUnit with the tripod on a flat and stable ground.
Perpendicular to the ground	ø	Check if the angle of the BaseUnit is perpendicular to the ground.
	6.	Arrange the components as shown on the picture on the left.
	ø	The distance between your putter with the mounted FlexTriplet and the BaseUnit should be approximately 0.5 m (20 inch).
	7.	Set up your PC or notebook close to the position from where you are going to putt.
spirit level	8.	Check the horizontal alignment with the spirit level on the backside of the BaseUnit.
universal	9.	If necessary, adjust the alignment with the universal joint of the tripod.
	✓	Sequence "Hardware installation" is completed!

Software installation

5. Software installation

Needed parts:





Software installation

SAM PuttLab 2008 Setup	 Accept the license agreement by checking the box below the agreement. Click the "Next" button.
SAM PutLab 2008 Setup Choose Install Location Choose Install Location Choose the folder in which to instal SAM PutLab 2008. Setup will instal SAM PutLab 2008 in the following folder. To install in a different folder, dick Browne and select another folder. Click Install to start the installation. Note: If you are updating or reinstalling SAM PutLab the destination folder cannot be Destination Folder Propriet S5.248 Space required: 55.248 Space requ	 A destination folder will be shown. Click the "Install" button or browse for a different destination. After setup procedure has copied all files to your hard disk, you will be asked to install the USB driver.
SAM PuttLab 2008 Setup	 6. Click the "Yes" button. Setup will analyze your operating system. 7. Click "OK" to continue.
Device Driver Installation Wizard Welcome to the Device Driver Installation Wizard! This wizard helps you install the software drivens that some computers devices need in order to work. To continue, click Nest.	 The Windows "Device Driver Installation Wizard" will appear. 8. Click on the "Next" button. Depending on the operating system you are using, Windows may ask you if you want to install the driver.

Software installation



 ✓ Sequence "Software installation" is completed.

6. Start the software for the first time



Be sure to have the Base unit connected to a USB port on your computer before you start the software!



Check if the LED inside the lower grid of the Base Unit is lit green! Otherwise the USB driver installation has failed. If so, repeat step "Software installation" of this Installation Guide!

SAM PL6 SAM PuttLab 6	 Double-click on the desktop icon to start the SAM PuttLab software. You can also start the software through the Window start-menu under "Programs > SAM PuttLab 6" (6 is the version number).
SAM PuttLab: Enter a new software key Please enter a valid software key:	You will be prompted to enter the software key printed on the software key document.
✓ OK X Cancel ? Help	The key which is provided to you is a unique key for your product. Keep it in a secure place.
	2. Type in the key and press the "Ok" button.
	With the input of the software key the software checks if the correct BaseUnit is connected to your PC.
	If you get an error message press the "Help" button on the software key dialog for help with problems during the registration.

Start the software for the first time

SAM PuttLab Wizard - create a project A project contains data from different players.	Help	The "SAM PuttLab Wizard" will appear.
At least one project must be existing to save any data. Insert a name for your first project into the following field (or just accept the given default project name): Project1 Optionally you can enter a description for your project in the field below: (e.g. 'Testproject training putts')		The data in the software is organized in projects that contain the corresponding players. For each player you can have several measurements.
, □ Don't show this wizard again ✓ Next	× Cancel	 Follow the instructions on the screen and create a first project and a player.
		After you have finished the process the Wizard will close and you will be re- directed to the main program window.
		If you need help on the input fields press the "Help" button on the Wizard pages at any time.
		✓ Sequence "Start the software for the first time" is completed.

7. Do your first measurement

7.1 Create a measurement



7.2 Execute the calibration

In this step the system will be calibrated to your putt position and direction. The calibration will be executed in the "Direct Calibration" mode. This means that firstly you should find your address position and hold your club stable in this position, then finally press the "C" button on your keyboard to calibrate.





- 1. Move to your putt position.
- Set the putter on the ground like shown in the picture on the left (ball in sweet spot of the putter head).
- 3. Place the Laser Alignment board directly behind the hole (the black line should be in the middle of the hole) or target position.
- Alternatively, you can place any other object behind the hole/target to make the laser beam visible (like the PuttLab suitcase).



- 4. Align the putter head exactly to the target by using the Laser and the Laser Alignment board.
 - Place the Laser on the putter like displayed in the picture on the left. The white line on the back of the Laser should meet the marking line or sweet spot of the putter.
 - Now activate the Laser by pushing the button on the barrel end.

	 Align the putter until the laser points to the target.
	You should now see the Laser beam on the center area of the Laser Alignment board or on the ball positioned in front of the hole. If this is not the case move the Laser until the beam is visible on the target object.
	Be sure the laser beam still points to the center.
5.	Hold your putter stable in the address position.
6.	Press the "C" on the keyboard or press the "execute direct calibration" button.
✓	After calibration has finished without an error message the system is calibrated and ready to record your putts.
e	If you are only one person working on the system, please use the "countdown calibration" button (please go to page 20 for more information).

The calibration of the system must be done after every software startup, every change of the ball position or target position, change of the putter and repositioning of the FlexTriplet on the golf club.

ø

Do your first measurement

7.3 Make your first putt

Status: Ready	 Hold the putter head still for 2 seconds before executing a stroke until the "Ready" signal on the top of the screen turns green. Then putt.
next putt 2 3	After you have made your putt you can verify if it has been recorded by checking the checked-off putts on the screen.
Save Recording × Session name (accept default or enter different name): Measurement - 30.10.2017 (M)	 3. Repeat step 1 and 2 until all strokes are recorded. <i>The strokes are recorded you will be are record</i>
Save Cancel	asked to save the recording. Press the Save button.
Sessions () 3D i Measurement - 30.10.2017 (M) 30.10.2017 (# 1)	 Congratulations! You've done your first measurements.
Reports	By double clicking on the session in the list or by clicking on the Reports button you can now open a result Report to review your putting results.

Don't forget to check out the help functions in the PuttLab software to get a maximum of information on all features of the software.

Press the F1 key in the main screen of the SAM PuttLab software to open the help overview page. Or open the settings and go to the "Program Help" page.

8. Important Information

8.1 LED Status of the FlexTriplet

Green – constant	FlexTriplet is activated and sending signals from the sensor.	Strokes can be made in front of the BaseUnit.
	You can hear a gentle buzzing noise.	
	If you don't make a measure the active mode lasts for 90 seconds. Then the FlexTriplet turns into standby mode.	
Green – flashing	FlexTriplet is in standby mode. The Standby mode lasts for 30 seconds. Then the FlexTriplet automatically turns off.	As soon as you move in front of the BaseUnit the FlexTriplet activates itself for measurements.
Red - flashing	Battery is empty.	Replace battery with a new one (see section 8.3 on the next page).

8.2 LED Status of the BaseUnit

After finishing the software and driver installation of the SAM PuttLab and connecting the BaseUnit for the first time there are two possible LED statuses:

Black / Off Driver installation is NOT	Green	Driver installation is working correctly.	You can make a measurement.
(does not light up) working correctly. Iight up) Be sure that the driver installation during the setup is executed (see page 9 – "Software Installation").	Black / Off (does not light up)	Driver installation is NOT working correctly.	Re-install the SAM PuttLab software. Be sure that the driver installation during the setup is executed (see page 9 – "Software Installation").

During the measurement different status will occur:

Red	BaseUnit is in measuring mode, but receives no signal from the triplet.	D	Be sure that the FlexTriplet is activated an in front of the BaseUnit.
Orange	Infrared connection is interrupted or the FlexTriplet is out of range.	ð	Be sure that the FlexTriplet is in front of the BaseUnit and that there are no objects/persons between unit and triplet.

8.3 Batteries for the FlexTriplet

Needed battery type	Lithium battery CR2 (photo battery)
Battery life (constant usage)	> 30 hours
Time until next battery change (daily use of 2 h)	> 30 days

If you have difficulties finding the batteries please contact Science & Motion Sports.

8.4 Calibration

8.4.1 Why is it so important

The calibration of the system must be done after every software startup, every change of ball position or the target position, change of the putter and repositioning of the FlexTriplet on the golf club. All the data will correspond to the ball position and the target direction from the calibration point. Without proper calibration the result data may be inconsistent and the reports differ from your real strokes. So, try to be very accurate while executing the calibration!

8.4.2 Correct calibration position



Important Information

8.4.3 Calibration methods

There are two ways to calibrate the SA	AM PuttLab system
Direct calibration	 Press the "C"-key or the "execute direct calibration" button the keyboard! ✓ The SAM PuttLab will be directly calibrated
	This is the best and easiest way to calibrate when you are more than one person working on the system.
Calibration via automatic countdown Sweet Spot Sweet Spot (prepare position) Mold position	 Press the "V"-key or the "calibration countdown" button on the keyboard! Find your address position during the countdown time (default: 15 seconds). Hold the club stable in the "hold position" at the end of the countdown.
	on the system.

	Personal notes	
). Personal notes		
<u> </u>		
	page 22 of 23	

10. More Info / contact

Science & Motion Sports

Website	www.scienceandmotion.com
E-Mail	info@scienceandmotion.com

© DA 10/17, Science&Motion Sports GmbH